

Tusk UTV Floor Mats



Congratulations on your purchase of the Tusk Floor Mats. This product is made to handle extreme riding conditions. Please take note of the information and instructions below to get the most out of your Tusk Product.

Note: For instructional videos, refer to www.rockymountainatvmc.com/videos.

Assembly: Before you throw any packaging away, make sure you received all the necessary hardware:

Installation steps:

1. Review kit contents and make sure all parts and hardware are included in the kit. Kit includes required floor mats (2 or 4 depending on kit) and 10-pack of 8mm push rivets. Installation will require the use of a drill and a 5/16" or 8mm drill bit.
2. Separate left and right side floor mats and install on correct sides. Verify that brake and throttle pedals function properly without any interference.
3. Using the drill and drill bit, locate 4 positions to drill through the floor mat and plastic floor. (Please verify that drill bit will not come in contact with any wires or other parts of the UTV when drilling through the plastic floor.) We recommend 2 rivets in the back of the floor mat underneath the seat, and 2 rivets along the side into the center console area. Please refer to the included pictures for ease of reference.
4. Extra rivets have been included for replacements. Please check the rivets regularly to insure proper function. Enjoy!

Rivet placement into side portion of the floor mat.



Rivet placement into rear portion of the floor mat.



Note: Check rivets and pedal clearances before and after every ride to insure proper function.