

Tusk UTV Fabric Roof Instructions Part # 1251840021

1. Loosely position the Tusk Fabric Roof over the roll cage with the "Front" tab on the underside of the roof to the front of the machine.

2. Unbuckle the front corner straps from the roof. Loop each front corner strap around the frame member down under the front wheel-well and route the strap back through the loop stitched in the end of the strap (see figs. 1, 2 and 3). Route the strap back up between the frame and the front fender by the dash (see fig. 4) and insert male buckle on strap into female buckle on front corner of roof. Repeat with other strap on opposite side.









3. Loop the rear side straps around the upper seat belt mounts and reattach the male and female buckles (see fig. 5). Leave straps loose.



5. Attach all the Velcro straps on the underside of the roof (see fig. 6).



6. Next, go around corner by corner and tighten the straps. Be sure to tighten the straps evenly so the roof fits symmetrically and snug over the roll cage. Go through and check your work to be sure all straps are tight and secure. You're now ready to ride with your new Tusk Fabric Roof!

<u>Warning</u>: To ensure the longevity of the Tusk Fabric Roof, it is recommended the roof is removed during transportation (trailering). The roof is designed with quick-release hardware for quick and easy removal before transporting the machine.